



## Manual

**go2key**

Product Version v25.2

July 4, 2025

## Imprint

PROCITEC GmbH  
Rastatter Straße 41  
D-75179 Pforzheim  
Germany

Phone: +49 7231 15561 0  
Fax: +49 7231 15561 11  
Email: [service@procitec.com](mailto:service@procitec.com)  
Web: [www.procitec.com](http://www.procitec.com)

CEO:  
Dipl.-Kaufmann / M. Sc. Stefan Haase

Registration Court:  
HRB 504702 Amtsgericht Mannheim  
Tax ID:  
DE 203 881 534

Document ID:  
PROCITEC-IMA-go2key\_E-45ba033524

All product names mentioned in this text are trademarks or registered trademarks of the respective title-holders.

© 2025 PROCITEC GmbH

All content, texts, graphics and images are copy-righted by PROCITEC GmbH, if not stated otherwise. Reproduction in any form, the rights of translation, processing, duplication, modification, use and distribution by use of electronic systems in whole or part are strictly prohibited.

Subject to technical modifications.

# Contents

<b>1. General</b>	<b>1</b>
1.1. Welcome to go2key	1
<b>2. Basics</b>	<b>2</b>
2.1. Software Start	2
2.2. Overview	2
2.2.1. Using the graphical user interface	2
2.2.2. Using the command line interface (CLI)	3
2.2.2.1. Basic workflow	3
2.2.2.2. Command line options	3
2.2.2.3. Details	3
2.2.2.4. Example execution	5
2.3. Key calculation algorithm	5
2.4. Keyboard Shortcuts (GUI)	6
<b>3. Workflow</b>	<b>8</b>
3.1. go2MONITOR	8
3.2. go2DECODE	11
<b>A. Support</b>	<b>17</b>
<b>List of Figures</b>	<b>18</b>
<b>List of Tables</b>	<b>19</b>



# 1. General

## 1.1. Welcome to go2key

The main purpose of go2key is the identification of an encryption *key* used to protect a radio transmission. Current version provides means for determination of an encryption key for DMR signals with ARC4 encrypted voice calls. Once the *key* is known, the decryption can be performed using standard workflow within any appropriate application within go2signals line, i.e. go2MONITOR or go2DECODE.

It includes the following features:

- determination of encryption *key* for DMR signals with ARC4 encrypted voice calls
- use of computational power of all CPU cores on a given machine
- interruption and resume of computation
- recall of recently recovered *keys*
- intuitive graphical user interface (GUI)
- powerful command line interface (CLI)

## 2. Basics

### 2.1. Software Start

To start go2key graphical user interface (GUI) click the desktop icon or use the operating system's start-menu. Using the command line interface requires, that the installation path of the go2key is known at the command line prompt. Either through appending it to the system's PATH variable or calling application with the full path of the go2key executable.

### 2.2. Overview

#### 2.2.1. Using the graphical user interface




Figure 1: go2key with computation in progress

The encryption key recovery requires input data in form of a sample of the digital transmission, i.e. encrypted voice frames. These data frames can be extracted using go2MONITOR or go2DECODE and stored into a JSON (\*.json) file. Please refer to chapter 3. Workflow on page 8 for details. Once a sample of encrypted voice frames (the JSON file) has been loaded, a list of *key-ids* used in the transmission appears in the drop down selection box. Computation is performed for selected *key-id*. If the amount and quality of the data sample is sufficient for key extraction then the „Find key“ button starts computation.

The log window shows current progress of computation including tested *key* range and estimated remaining time. Some additional information is also presented in case data quality does not guarantee successful key recovery.

The computation can be paused at any time by „Stop“ button. Pressing „Find key“ again resumes data processing. The GUI application preserves the key extraction state for a given JSON file and selected *key-id* for a few recently executed computations. It means, that in case of intentional or accidental termination of the application, e.g. closing of the GUI window, system shutdown or power outage, the key extraction can be resumed from the last known state.

The number of threads used for computation (parallelization) is chosen automatically based on the capabilities of the CPU. On systems with Microsoft Windows the number of used threads is reduced by two, otherwise the user interface might get unresponsive.

## 2.2.2. Using the command line interface (CLI)

The command line interface to the go2key application is meant for expert users. It allows detailed parametrization of input data and key ranges to be tested. The computation state, i.e. which key ranges have been already tested and which files have already been processed must be handled by the operator.

### 2.2.2.1. Basic workflow

- Extract voice data frames as described in chapter 3. Workflow on page 8
- List superframes and get overview of recorded data:  
`go2key list <path_to_json_file>`
- Select the *key-id* for key extraction
- Run the application  
`go2key crack --key_id <selected_key_id> --auto_select <path_to_json_file>`
- Wait until key is found or no key is found after all keys have been tried.
- Decrypt voice: Place found *key* in decoder parameters of DMR decoder with appropriate *key-id*. Process the recording again with modified decoder parameters.

### 2.2.2.2. Command line options

**crack** runs the key extraction algorithm

**list** shows an overview of superframes in json file

**benchmark** runs the key extraction algorithm with random input data and shows the processing speed

### 2.2.2.3. Details

#### Options

```
1 >> go2key -h
2 usage: DMR go2key [-h] {list,benchmark,crack} ...
3
4 positional arguments:
5   {list,benchmark,crack}
6     list lists/shows superframes in record file
7     benchmark benchmark cracking speed
8     crack cracking of ARC4 encrypted voice
9
10 options:
11   -h, --help show this help message and exit
```

*Listing 2.1: Command line help to general options*

### Option 'crack'

```
1 >> go2key crack -h
2 usage: DMR go2key crack [-h] [-i IDENT] [-v VALIDATION] [-a] -k KEY_ID [-s START_KEY] [-e END_KEY] [--
   num_threads NUM_THREADS] [--full] input
3
4 positional arguments:
5   input Record file with encrypted superframes.
6
7 options:
8   -h, --help show this help message and exit
9   -i IDENT, --ident IDENT
10                        Superframe used for identification. Use command 'list' to see available frames. Not
                        allowed if option '--auto_select' is
                        used. (default: None)
11   -v VALIDATION, --validation VALIDATION
12                        Superframes used for validation. It is allowed to use identification again. Not
                        allowed if option '--auto_select' is used.
13                        Allowed are 3 to 10 superframes. Recommendation: Use 6 or more for higher success
                        probability. Format: Comma separated list.
14                        Example: "0,2,3,8,11,44" (default: None)
15   -a, --auto_select Auto-select frames used for cracking. '--ident' and '--validation' are not allowed. (
                        default: False)
16   -k KEY_ID, --key_id KEY_ID
17                        Crack this key id. (default: None)
18   -s START_KEY, --start_key START_KEY
19                        Start cracking with this key, has to be 0 or multiple of 256. (default: 0)
20   -e END_KEY, --end_key END_KEY
21                        Stop cracking with this key (exclusive), has to be multiple of 256 and > start key.
22                        (default: 1099511627776)
23   --num_threads NUM_THREADS
24                        Number of threads to use. If not given, the cpu count of the system is used (24). (
                        default: None)
25   --full Search full key space. Otherwise key cracking is aborted if the key is found. (default: False)
```

Listing 2.2: Command line help, "crack" option

### Option 'list'

```
1 >> go2key list -h
2 usage: DMR go2key list [-h] [-k KEY_ID] input
3
4 positional arguments:
5   input Record file with encrypted superframes.
6
7 options:
8   -h, --help show this help message and exit
9   -k KEY_ID, --key_id KEY_ID
10                        Only show superframes with this key id.
```

Listing 2.3: Command line help, "list" option

### Option 'benchmark'

```
1 >>go2key benchmark -h
2 usage: DMR go2key benchmark [-h] [--num_threads NUM_THREADS]
3
4 options:
5   -h, --help show this help message and exit
6   --num_threads NUM_THREADS
7                        Number of threads to use. If not given, the cpu count of the system is used.
```

Listing 2.4: Command line help, "benchmark" option



### 2.2.2.4. Example execution

```

1 >> go2key list ~/procitec/analysis suite 25.1/mem_prod/20230302/20230302-143420-552__0000000000_D01.json
2 Record Summary
3 Superframes : 53
4 Key ID 1 : 53
5 Detailed Frame List
6 Index KeyID AlgID Errors Complete IV Time
7 -----
8 0 1 1 0 T 7f5d51c9 2023-03-02 14:34:01.503490+00:00
9 1 1 1 0 T 869044a9 2023-03-02 14:34:01.863490+00:00
10 2 1 1 0 T 423ca71f 2023-03-02 14:34:02.223510+00:00
11 3 1 1 1 T 6f0fb018 2023-03-02 14:34:02.583490+00:00
12 4 1 1 0 T d792144f 2023-03-02 14:34:02.943490+00:00
13 5 1 1 0 T dd029b30 2023-03-02 14:34:03.303490+00:00
14 6 1 1 0 T e9e5ab51 2023-03-02 14:34:03.663510+00:00
15 7 1 1 0 T 95cbee3d 2023-03-02 14:34:04.023490+00:00
16 8 1 1 0 T 04abbb5f 2023-03-02 14:34:04.383470+00:00
17 9 1 1 0 T 3964c692 2023-03-02 14:34:04.743490+00:00
18 10 1 1 0 T bdcadc47 2023-03-02 14:34:05.103490+00:00
19 ...
20 50 1 1 0 T eadb7aba 2023-03-02 14:34:19.503430+00:00
21 51 1 1 0 T fb83aabe 2023-03-02 14:34:19.863450+00:00
22 52 1 1 0 T bf9d34c2 2023-03-02 14:34:20.223410+00:00
23
24 >> go2key crack -k 53 -a ~/procitec/analysis suite 25.1/mem_prod/20230302/20230302-143420-552
    __0000000000_D01.json
25 Start to crack the key with identification-frame=0 and validation-frames=[0, 1, 2, 4, 5, 6, 7, 52]
26 Quality of recorded data within computation : 100%
27 0.006% 31654484 keys/s remaining: 9:38:52 (0x0004100000)
28 0.012% 31624105 keys/s remaining: 9:39:23 (0x0008100000)
29 0.018% 31659621 keys/s remaining: 9:38:42 (0x000C100000)
30 0.025% 31641042 keys/s remaining: 9:39:01 (0x0010100000)
31 0.031% 31658694 keys/s remaining: 9:38:39 (0x0014100000)
32 0.035% 30871366 keys/s remaining: 9:53:23 (0x0016C00000)
33 0.041% 30848803 keys/s remaining: 9:53:47 (0x001A700000)
34 0.047% 30859882 keys/s remaining: 9:53:32 (0x001E700000)
35
36 ...
37
38 0.432% 29292910 keys/s remaining: 9:50:52 (0x011A900000)
39 0.437% 29203317 keys/s remaining: 9:50:45 (0x011E200000)
40 0.443% 29540925 keys/s remaining: 9:50:35 (0x0122000000)
41 -----
42 KEY FOUND: 0x0123456789 (match)
43 -----
44 Aborting. Wait for worker threads to join.
45
46
47 FINISHED
48 CHECKED 4876926976 KEYS
49 CONTIGUOUS RANGE 0x0000000000 TO 0x0122200000 (excluding)
50 FOUND 1 KEY
51 0x0123456789 (match)

```

Listing 2.5: Command line execution example

## 2.3. Key calculation algorithm

For a DMR voice transmission, the AMBE2+™ codec from DVS I is used.

- Voice is encoded in 20 ms long voice frames.
- A voice frame consists of 49 data bits and 23 bits of forward error correction.
- 18 voice frames are combined into one super frame.
- A super frame thus consists of 882 data bits and encodes 360 ms of voice.

This frame structure is used for encryption and is relevant for the parameterization of the key calculation algorithm.

ARC4 is a stream cipher and used to encrypt and decrypt the data bits. A 40-bit key is used for this, therefore there are a total of  $2^{40} - 1 = 1\,099\,511\,627\,775$  keys (0 not allowed). If the correct key is known, anyone can decrypt a voice transmission.

To crack the key, a brute force approach is used here and all keys are tested.

- If an incorrect key is used, you get pseudo-random bits.
- If the correct key is used, valid data is obtained.

To distinguish the single correct key from the all  $2^{40} - 2$  wrong keys, the content of the transmission is analyzed. For a unique recognition, the calculation algorithm needs several super frames (3-10). These do not have to be consecutive or from the same transmission, but of course the same key must have been used. Each key is assigned a *key-id* and is always sent unencrypted. Therefore, the authorized receiving device knows which key was used to encrypt the data. Transmissions from the same source with the same *key-id* generally suggest that the same 40 bit key was used.

To speed up the key calculation, the algorithm is divided into 2 sections, which are called here identification and validation.

- the identification step uses a single superframe (identification superframe)
- the validation step uses multiple superframes (validation superframes)

During identification, a very fast calculation method discards a large proportion of incorrect keys. The remaining wrong keys are excluded within the validation step. Only the correct key is recognized as correct by the validation. The super frame for identification can also be used for validation.

Since bit errors can occur during radio transmissions, only those superframes should be used for key calculation which contain as few bit errors as possible. If the signal was received with poor quality, there may be too many bit errors in the data to calculate the correct key. In this case the algorithm returns no result. The number of bit errors is estimated based on the transmitted forward error correction bits. In addition, it is necessary that the superframes used for the key calculation contain different encryption initialization vectors.

In order to make a good selection of superframes from all received superframes, an automatism was implemented. However, it is also possible to specify the superframes manually. This specification must be a single identification superframe and between 3 and 10 superframes for validation. If possible, at least 8 validation superframes should be used. Since a superframe is transmitted every 360 ms, there should usually be enough data available.

It is very unlikely that the algorithm will return a false key (false positive probability) or fail to recognise the correct key (false negative probability). Both probabilities depend on the number of superframes used in the validation and were determined empirically with generated bit error-free test data. The false positive probability is smaller than  $10^{-6}$  in all cases. The false negative probability is given in the following table depending on the number of superframes.

N	3	4-6	7-8	9-10
PN	<0.027	< $4.6 \cdot 10^{-4}$	< $2.4 \cdot 10^{-6}$	< $1.3 \cdot 10^{-10}$

If, contrary to expectations, no key is found with error-free data, the search can be repeated with other super frames.

## 2.4. Keyboard Shortcuts (GUI)

Function	Shortcut
<Load file>	<Ctrl>+<O>
<Copy key>	<Ctrl>+<K>
<Save key>	<Ctrl>+<S>
<Manual>	<F1>
<Copy>	<Ctrl>+<C>
<Select all>	<Ctrl>+<A>
<Exit>	<Ctrl>+<Q>

*Table 1: Keyboard Shortcuts*

## 3. Workflow

In the following chapter we describe the complete workflow of using go2key with go2MONITOR and go2DECODE.

Note: the workflow for "DMR" and "DMR continuous" are identical but for simplicity only "DMR" is described here.

### 3.1. go2MONITOR

In case an emission has been detected and produced within go2MONITOR, the following steps are necessary for the production of a decrypted voice transmission.

- Start decoding the DMR signal to be decrypted in a go2MONITOR production channel




Figure 2: go2MONITOR production channel

- Right-click on the decoder to open the decoder parameters




Figure 3: go2MONITOR decoder parameter editor with default DMR modem

and check "Record voice frames"




Figure 4: go2MONITOR decoder parameter editor with DMR where voice frame recording is enabled

- The signal has to be processed again in order to extract voice frames and save them into a .json file. Files can be found in the results window by setting the filter to "Files"




Figure 5: go2MONITOR production channel with voice frame recording results

- Open the file explorer by clicking on [DIR] and drag&drop the .json recording into go2key



Figure 6: go2key with loaded voice frame recording

- Start key search with the „Find key“ button




Figure 7: go2key with computation in progress

- Wait until go2key detects the correct key




Figure 8: go2key with encryption key found

- The key and key-id need to be entered into decoder parameter form in go2MONITOR (note: omit the leading "0x" for the key ).




Figure 9: go2MONITOR decoder parameter editor with DMR, encryption key and key-id are parametrized

- Restart decoding, the signal is processed again, this time decrypting the voice data with the correct key




Figure 10: go2MONITOR production channel with audio results

The audio can be monitored during the processing through headphones or speakers. At the end of processing an audio file containing decrypted contents is reported in the decoder results window.

For details regarding modification of decoder parameters and handling of modified modem descriptions please refer to go2MONITOR user manual.

## 3.2. go2DECODE

In case an emission has been detected and produced within go2DECODE, the following steps are necessary for the production of decrypted voice transmission.

- Add DMR modem to the modem list.
- Open "Decod" tab for decoder parameters and make sure "Record voice frames" checkbox is selected.




Figure 11: go2DECODE decoder parameters

- Process emission in order to create .json file with extracted voice frames.




Figure 12: go2DECODE DMR signal production

- Find the corresponding voice frames extraction in a .json file.  
There are two options available:
  1. Deactivate "XML tag filter" in "Result display" parameters and find the path to the .json result file in the result raw XML, see Figure 13






Figure 13: go2DECODE, access produced files

- Open PMO from go2DECODE "Extras" menu. In PMO select date and "Binary Results" tab, see Figure 14.




Figure 14: go2DECODE, use PMO to identify the .json file

- Open the .json file in go2key.




Figure 15: go2key with loaded voice frame recording

- Start key search with the „Find key“ button.




Figure 16: go2key with computation in progress

- Wait until go2key detects the correct key




Figure 17: go2key with encryption key found

- The key and key-id need to be entered into decoder parameter form in go2DECODE (note: omit the leading "0x" for the key ).




Figure 18: go2DECODE, decoder parameters for DMR with parametrized encryption key and key-id

- Restart decoding, the signal is processed again, this time decrypting the voice data with the correct key. For live playback please turn on "Audio out" from "Extras" menu or toolbar and set "Mode" to "Digital"




Figure 19: go2DECODE, audio playback and DMR modem with parametrized encryption key and key-id

- The decrypted audio recording can be found as a .wav file using PMO (see Figure 20) or by peeking into raw XML result stream (see Figure 13).




Figure 20: go2DECODE, use PMO to identify and play the .wav file

For details regarding modification of decoder parameters and handling of modified modem descriptions please refer to go2DECODE user manual.


## A. Support

### Requests and suggestions?

All requests or suggestions regarding our go2signals product-range are very much appreciated; we would be delighted to hear from you.

### Any questions? We are happy to assist you!

If you have any further questions, please do not hesitate to contact our Support Team for rapid assistance – just raise a service request at: <http://servicedesk.procitec.com>.



PROCITEC Service Desk


**Log in to PROCITEC Service Desk**

**Where are my Tickets?**  
We have transferred all tickets into one category. They are still here but are now called "Problem reporting". If you consider any problems, please contact [service@procitec.de](mailto:service@procitec.de)  
Your PROCITEC Customer Service Team

Email

**Next**

Need an account? [Sign up](#)

Powered by  Jira Service Management

PROCITEC GmbH  
Rastatter Straße 41  
D-75179 Pforzheim  
Phone: +49 7231 15561 0  
Web: [www.procitec.com](http://www.procitec.com)  
Email: [service@procitec.com](mailto:service@procitec.com)

## List of Figures

1.	go2key with computation in progress . . . . .	2
2.	go2MONITOR production channel . . . . .	8
3.	go2MONITOR decoder parameter editor with default DMR modem . . . . .	8
4.	go2MONITOR decoder parameter editor with DMR where voice frame recording is enabled . . . . .	9
5.	go2MONITOR production channel with voice frame recording results . . . . .	9
6.	go2key with loaded voice frame recording . . . . .	9
7.	go2key with computation in progress . . . . .	10
8.	go2key with encryption key found . . . . .	10
9.	go2MONITOR decoder parameter editor with DMR, encryption <i>key</i> and <i>key-id</i> are parametrized . . . . .	10
10.	go2MONITOR production channel with audio results . . . . .	11
11.	go2DECODE decoder parameters . . . . .	11
12.	go2DECODE DMR signal production . . . . .	12
13.	go2DECODE, access produced files . . . . .	13
14.	go2DECODE, use PMO to identify the .json file . . . . .	13
15.	go2key with loaded voice frame recording . . . . .	14
16.	go2key with computation in progress . . . . .	14
17.	go2key with encryption <i>key</i> found . . . . .	14
18.	go2DECODE, decoder parameters for DMR with parametrized encryption <i>key</i> and <i>key-id</i> . . . . .	15
19.	go2DECODE, audio playback and DMR modem with parametrized encryption <i>key</i> and <i>key-id</i> . . . . .	16
20.	go2DECODE, use PMO to identify and play the .wav file . . . . .	16

# List of Tables

1. Keyboard Shortcuts . . . . . 7